PERIODIC MAINTENANCE SCHEDULE

The chart below lists the recommended intervals for all the required periodic service work necessary to keep the motorcycle operating at peak performance and economy. Mileages are expressed in terms of kilometers, miles and time for your convenience.

NOTE:

More frequent servicing may be performed on motorcycles that are used under severe conditions.

PERIODIC MAINTENANCE CHART

miles 600 4 000 7 500 11 000 14 500 months 2 12 24 36 48 Air cleaner element							
Item	Interval		1 000	6 000	12 000	18 000	24 000
Minims 2 12 24 35 48		miles	600	4 000	7 500	11 000	14 500
Exhaust pipe bolts and muffler bolts	Item	months	2	12	24	36	48
Valve clearance — — — I Spark plugs — I R I R Fuel line — I R I	Air cleaner element		_	I	I	R	I
Spark plugs	Exhaust pipe bolts and muffler bolts		Т	Т	Т	Т	Т
Fuel line	Valve clearance		_	_	_	_	-
Replace every 4 years	Spark plugs		_		R		R
Engine oil R	Fuel line		_		I	I	
Engine oil filter			Replace every 4 years				
Idie speed	Engine oil		R	R	R	R	R
Throttle cable play	Engine oil filter		R	_	_	R	_
Throttle valve synchronization	Idle speed		I				
Evaporative emission control system (E-33 only)	Throttle cable play		I	I	I	I	I
Evaporative emission control system (E-33 only)			ı	_	I	_	I
(E-33 only) Replace vapor hose every 4 years. PAIR (air supply) system — — I — I Engine coolant Replace every 2 years. — I <td colspan="2"></td> <td>(E-33 only)</td> <td></td> <td></td> <td></td> <td></td>			(E-33 only)				
PAIR (air supply) system — I — I Engine coolant Replace every 2 years. Radiator hoses — I	Evaporative emission control system		_	_	1	_	1
Engine coolant Replace every 2 years. Radiator hoses —			Replace vapor hose every 4 years.				
Radiator hoses	PAIR (air supply) system		_	_	I	_	1
Replace every 4 years.	Engine coolant		Replace every 2 years.				
Clutch — I <td colspan="2">Radiator hoses</td> <td>_</td> <td>I</td> <td>I</td> <td>I</td> <td>I</td>	Radiator hoses		_	I	I	I	I
Drive chain I <th< td=""><td colspan="2"></td><td colspan="5">Replace every 4 years.</td></th<>			Replace every 4 years.				
Clean and lubricate every 1 000 km (600 miles). Brakes I </td <td colspan="2">Clutch</td> <td>_</td> <td> </td> <td>I</td> <td>1</td> <td></td>	Clutch		_		I	1	
Brakes I <td colspan="2">Drive chain</td> <td>I</td> <td>l</td> <td></td> <td>I</td> <td></td>	Drive chain		I	l		I	
Brake hose — I			Clean and lubricate every 1 000 km (600 miles).				
Replace every 4 years.	Brakes		I	I	I	I	I
Brake fluid — I I I I Replace every 2 years. Tires — I			_	I	I	I	
Replace every 2 years. Tires — I I I Steering I — I — I			Replace every 4 years.				
Tires — I I I I Steering I — I — I	Brake fluid		_	I	I	I	I
Steering			Replace every 2 years.				
Ť			_				
Front forks	<u> </u>		I	_	I	_	I
	Front forks		_	_		_	
Rear suspension — — I — I	Rear suspension				l l	_	I
Chassis bolts and nuts T T T T	Chassis bolts and nuts		Т	Т	Т	Т	Т

NOTE:

I=Inspect and clean, adjust, replace or lubricate as necessary;

R=Replace; T=Tighten