

PERIODIC MAINTENANCE SCHEDULE

The chart below lists the recommended intervals for all the required periodic service work necessary to keep the motorcycle operating at peak performance and economy. Mileages are expressed in terms of kilometers, miles and time for your convenience.

NOTE:

More frequent servicing may be performed on motorcycles that are used under severe conditions.

PERIODIC MAINTENANCE CHART

Item	Interval	miles	600	4 000	7 500	11 000	14 500
		km	1 000	6 000	12 000	18 000	24 000
		months	1	6	12	18	24
Air cleaner element		Clean every 3 000 km (1 800 miles)					
Exhaust pipe bolts and muffler bolts		T	T	T	T	T	
Valve clearance		I	I	I	I	I	
Spark plug		—	I	R	I	R	
Fuel line		—	I	I	I	I	
		Replace every 4 years					
Engine oil		R	R	R	R	R	
Engine oil filter		R	—	—	R	—	
Final gear oil		—	—	R	—	R	
Idle speed		I	I	I	I	I	
Throttle cable play		I	I	I	I	I	
Cooling fan filter		Clean every 3 000 km (1 800 miles)					
Radiator hose		—	I	I	I	I	
		Replace every 4 years					
Engine coolant		Replace every 2 years					
Drive V-belt		—	—	I	—	R	
Evaporative emission control system E-33 (California) model only		—	—	I	—	I	
		Replace vapor hose every 4 years					
PAIR (air supply) system		—	—	I	—	I	
Brake		I	I	I	I	I	
Brake hose		—	I	I	I	I	
		Replace every 4 years					
Brake fluid		—	I	I	I	I	
		Replace every 2 years					
Steering		I	—	I	—	I	
Front fork		—	—	I	—	I	
Rear suspension		—	—	I	—	I	
Tire		I	I	I	I	I	
Chassis bolts and nuts		T	T	T	T	T	

NOTE:

I=Inspect and clean, adjust, replace or lubricate as necessary;

R=Replace; T=Tighten