

## PERIODIC MAINTENANCE SCHEDULE

The chart below lists the recommended intervals for all the required periodic service work necessary to keep the motorcycle operating at peak performance and economy. Maintenance intervals are expressed in terms of kilometer, miles and months, and are dependant on whichever comes first.

### NOTES:

More frequent servicing may be performed on motorcycles that are used under severe conditions.

### PERIODIC MAINTENANCE CHART

Item	Interval	km	1 000	6 000	12 000	18 000	24 000
		miles	600	4 000	7 500	11 000	15 000
		months	1	6	12	18	24
Air cleaner		-	I	I	R	I	
Spark plugs		-	I	R	I	R	
Tappet clearance		-	-	-	-	I	
Engine oil		R	R	R	R	R	
Engine oil filter		R	-	-	R	-	
Fuel hose		-	I	I	I	I	
Replace every 4 years.							
Engine idle speed		I	I	I	I	I	
Throttle valve synchronization		I (E-33 only)	-	I	-	I	
Evaporative emission control system (E-33 only)		-	-	I	-	I	
Replace vapor hose every 4 years.							
PAIR (air supply) system (E-33 only)		-	-	I	-	I	
Throttle cable play		I	I	I	I	I	
Clutch hose		-	I	I	I	I	
Replace every 4 years							
Clutch fluid		-	I	I	I	I	
Replace every 2 years							
Radiator hoses		-	I	I	I	I	
Engine coolant		Replace every 2 years					
Drive chain		I	I	I	I	I	
Clean and lubricate every 1 000 km (600 miles).							
Brakes		I	I	I	I	I	
Brake hoses		-	I	I	I	I	
Replace every 4 years.							
Brake fluid		-	I	I	I	I	
Replace every 2 years.							
Tire		-	I	I	I	I	
Steering		I	-	I	-	I	
Front forks		-	-	I	-	I	
Rear suspension		-	-	I	-	I	
Exhaust pipe bolt and nut		T	-	T	-	T	
Chassis bolt and nuts		T	T	T	T	T	

I = Inspect and adjust, clean, lubricate or replace as necessary.

R = Replace

T = Tighten